

Pre-rinse replacement flexible hose

Bridgepoint SKU ID09400FL200 | Idral code 09400FL200

Installation sequence

1. Isolate the water supply and release the pressure before removing the existing component. Identify the fitted pre-rinse assembly and match the replacement article code and connection fittings.
2. Route the replacement hose through the support spring where fitted. Connect both ends with the correct gaskets, keeping the hose free of tension, twisting and tight bends. Maintain the approximately 90 mm minimum bend radius described in the pre-rinse family manual.
3. Restore the supply gradually and check all joints for leaks. Move the assembly through its working range and confirm the hand shower opens and closes correctly.

Important

Use the parent pre-rinse assembly instructions and its operating limits. A hose or hand shower is a replacement component, not a complete mixer.

Verify the exact hose length, end fittings and compatibility with the supplier before ordering or installation.

Source: Idral ISTA40-02. This summary accompanies the original manufacturer instructions. Shared family references apply only to the matching components; use the exact product instructions and drawings for the complete installation.