

Pre-rinse shower assembly 1200 mm

Bridgepoint SKU ID09420 | Idral code 09420

Installation sequence

1. Have a qualified installer prepare the connections using the manufacturer drawing and the instructions supplied with the product. Purge the supply pipes before connection and provide suitable water filtration.
2. Fix the pre-assembled supply pipe to the selected compatible tap or mixer using ISTA40-02 Figures 01-02. The mixer or tap base is selected separately.
3. Where the support arrangement is fitted, position the ring, rod and hook as shown in Figure 01b. Adjust the wall distance before finally securing the wall cover.
4. Route the hose through the spring and connect it to the supply pipe with the supplied gasket. Fit the hand shower with its gasket and keep the hose free of tension and tight bends.
5. Fit the telescopic swivel spout to the middle outlet. Check its movement and adjust the reach within 200-300 mm.
6. Open the supply, check for leaks and test the spray lever and continuous-flow hook. Confirm the lever closes correctly when released with the hook disengaged.

Important

Operating range: 1-6 bar; recommended 2-4 bar; water temperature 5-65 °C. Follow the exact model drawing for the assembly height and mounting arrangement.

Source: Idral ISTA40-02. This summary accompanies the original manufacturer instructions. Shared family references apply only to the matching components; use the exact product instructions and drawings for the complete installation.