Installation Guidance

Two-control mixer base

Bridgepoint SKU ID09450/LDC | Idral code 09450/LDC

Installation sequence

1. Have a qualified installer prepare the connections using the manufacturer drawing and the instructions supplied with the product. Purge the supply pipes before connection and provide suitable water filtration.

2. Set the wall connections to the centres shown in the exact drawing and secure the tap or mixer with the supplied seals and connection fittings.

3. Connect a compatible separately selected spout or pre-rinse assembly to the G3/4 outlet.

4. Open the supplies, check every connection for leaks and test the lever or handle controls through their full range. Verify mixing on two-supply models and proper closure.

Important

Use the product-specific pressure and temperature limits shown in the Technical Specification. Protect the fitting from freezing.

The shared ISTA38-01 installation manual specifies 1-6 bar (2-4 bar recommended) and 5-65 °C. Use this narrower installation range where the technical sheet permits higher temperatures.

Source: Idral ISTA38-01. This summary accompanies the original manufacturer instructions. Shared family references apply only to the matching components; use the exact product instructions and drawings for the complete installation.