

Pre-rinse mixer kit 900 mm

Bridgepoint SKU IDKPR00/80 | Idral code KPR00/80

Routine care

Clean exposed surfaces with water and mild soap. Avoid aggressive or abrasive cleaners and dry with a soft cloth.

Isolate the water supply before dismantling or replacing components. Purge the upstream pipes after a shutdown before returning the unit to service.

For the 09401 hand shower, unscrew the shockproof diffuser to access the interchangeable disc. Reassemble with the gasket correctly seated; the green Greenflow disc reduces flow from approximately 12 to 6 L/min.

The detached 09401 hand shower may be cleaned in a dishwasher at a temperature no higher than 90 °C. This cleaning permission applies to the hand shower.

Check the hose, spring and support fixings for damage or looseness and verify the lever closes the water after service.

Service

Use the product instructions supplied with the unit for complete dismantling and service procedures.

Source: Idral ISTA40-02. This summary accompanies the original manufacturer instructions. Shared family references apply only to the matching components; use the exact product instructions and drawings for the complete installation.